

*** Note on Filler Neck and Cap**

-Filler neck - The cowling will be 1.5 inches above the top of the tank where the filler neck is, so the neck should be long enough to protrude past the cowling with the oil cap being completely outside the cowling...I am guessing about 3 to 3.5 inch total length for the filler neck and oil cap, assuming the cap is not thicker than one inch..